707 - STOVE TOP CLEANER

STOVE TOP CLEANER, efficiently removes burnt in food residues without scratching. Stove Top Cleaner, polishes and protects in the same operation, leaving the hob glossy and with a protective film that makes future cleaning easier.

Instructions

Apply on a dry cloth and polish the cold surface until the plate is clean and shiny. If necessary, wipe excess polish. Use of scraper is not necessary.

Declaration

Contains: <5% non- and cat-ionic surfactants, >30% aliphatic hydrocarbons. Also contains: abrasives, water, silicone oil, citric acid and perfume.

WARNING: Keep out of reach of children.



Conditioning 250ml (12 units/box) / 500ml (12 units/box)

If you have any questions, please contact our Technical Department on: +45 4817 6970



NGL NORDIC A/S Industriskellet 10 – DK-2635 Ishøj – Denmark info@ngl-nordicare.com – Tel: +45 4817 6970 www.ngl-nordicare.com